Samsung ATIV Book 4 Hard Drive Replacement

This guide will show you how to remove and replace the hard drive on your device.

Written By: Chad



INTRODUCTION

This computer is equipped with a 1 TB hard drive. Whether the hard drive has went bad and needs replacement or if you want to upgrade to a larger and quicker one, this guide will help you complete this task.

TOOLS:

- Phillips #00 Screwdriver (1)

Step 1 — Hard Drive



- Place the computer upside down.
- Remove one 6.5mm screw on exterior of computer.

Step 2






- Remove the panel by sliding it down and lifting it away from the computer, exposing the RAM and hard drive.

Step 3





- Remove the four 4.4mm screws securing the hard drive.
- Remove the harness from hard drive.
- Remove and replace the hard drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-30 08:18:38 PM.